Touch screen

By touching the screen with your finger, you can control the audio system and air-conditioning, adjust the screen display etc.

► Vehicles with navigation system



► Vehicles without navigation system



The "Information" screen shown in the above illustration is displayed when the pressed.

Switches	Page
"CLIMATE"	P.191
"AUDIO"	P. 200
"INFO" (Displaying the "Information" screen)	P.182
"DISP" (Adjusting the display)	P.186
Trip Information. (Displaying the "Trip Information" screen)	P.6
Maintenance	Navigation System Owner's Manual
Telephone	P. 268
Calendar	Navigation System Owner's Manual
"LEXUS Park Assist"	P.153
Language	P.185
Screen Setting	P.188
Adjust Clock	P. 319/ Navigation System Owner's Manual

The initial screen



If the power switch is set to "ACC" or "IG-ON" mode, the initializing screen will be displayed for a few seconds as the system starts up.

n To avoid damaging the touch screen

- 1 Touch the screen lightly with your finger. If there is no response, remove your finger from the screen and try again.
- 1 Remove any dirt on the screen by wiping with a soft cloth. Do not use detergent.

n When using the touch screen

- 1 If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.
- 1 The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, or remove your sunglasses.

You can change the touch screen to your desired settings.

Language settings

The language used for all voice guidance, messages and touch screen switches may be changed.



STEP 2 Touch on the "Information" screen.



Select the desired language.

STEP 4 Touch OK.

Turning off the beep sound

The beep that sounds when a touch screen button is touched can be turned off.





Touch Beep Off.

Adjusting the display

STEP 1 Press OISP.

If you do not touch the screen for 20 seconds, the system will return to the previous screen.

► Vehicles with DVD player



► Vehicles with CD player





n "Day Mode"



When the headlights are turned on, the screen dims. However the screen can be switched to "Day Mode".

The screen will stay in "Day Mode" when the headlights are turned on until is touched again.

If the instrument panel light control is set to "MAX", "Day Mode" is not displayed.

n To turn off the picture display

If some is touched, the screen display is turned off, and guidance is by voice only.

Screen settings

The following screen settings can be changed.



Automatic transition

20 seconds after air-conditioning or audio system use, the system will return the display to the previous screen.

2 Switch color

You can select the switch color.

3 Personal data deletion

The following personal data is deleted:

- User selection settings
- Phone book data
- Dialed numbers and received calls
- Speed dial
- Bluetooth® phone data
- Security code
- Maintenance conditions*
- Maintenance information "off" setting*
- Memory points*
- Areas to avoid*
- Previous points*
- Route trace*
- *: If the navigation system is equipped

n Setting automatic transition

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch ON or OFF on the "Screen Setting" screen.

STEP 4 Press OK.

n Setting the switch color

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch Blue or Gold on the "Screen Setting" screen.

STEP 4 Press OK.

n To delete personal data

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch the _____ on the "Screen Setting" screen.



Touch Delete.

Check carefully beforehand, as data cannot be retrieved once initialized.

${\rm n}\,$ When deleting personal data

Data can only be deleted when the vehicle is stopped.

n When selling the vehicle

Be sure to initialize both the call history and personal data. $(\rightarrow P.188)$

n If you touch the 🔼

The display returns to the previous screen.